


DETAILED DRAWING



10A/30A - SLIP RING COLLECTOR

COMPONENTS

Reference	Code	Description
01	PRVI0033PE	Screw 3x7.5
02	PRFU6052PE	Nut
03	PRFU6042PE	Ring - pitch 1.5
04	PRTO6207PE	Terminal
05	PRVI1004PE	Screw M4x4
06	PRVI0136PE	Screw M4x6
07	PRDA6005PE	Nut
08	Codes on request	Rod
09	PRVI0106PE	Screw 4x10
10	PRVI0146PE	Screw M4x12
11	PRSL9155PI	Hexagonal seat short brush holder
12	PRTO6206PE	Line brush terminal
13	PRTO0486PE	Brush holder rotor rod
14	PRSL9110PI	Standard brush holder
15	PRVO6016PI	Screw M4x6
16	PRSL9160PI	Screw seat short brush holder
17	PRRN6005PE	Washer
18	PRMO0032PE	Brush holder spring-hook
19	PRSL8555PI	Guide pin
20	PRVV9990PE	Elastic ring
21	Codes on request	Protection rod
22	PRSL8542PI	Bearing covering ring
23	PRRN1061PE	Washer
24	PRTO6201PE	Screw
25	PRFU6032PE	Ring - pitch 1
26	PRSL5110PI	Sector
27	PRTO6167PE	Closing screw
28	PRFU3101PE	Lower plate
29	PRCB0011PE	Ball bearing
30	PRFU3111PE	Upper plate
31	PRDA0023PE	Nut
32	PRVV1007PE	Elastic pin 3x18 ISO8752
33	PRTR4061PE	Auxiliary brush
34	PRRN1032PE	Washer
35	PRVI6031PE	Screw M4x12
36	PRTR4058PE	Line brush
37	PRSL8565PI	Spacer 2mm
38	PRTR4062PE	Earth brush
39	PRRN9002PE	Washer
40	PRPS0044PE	Cable clamp M25
41	PRGU4014PE	O-Ring
42	PRRN0044PE	Washer 4.3x9x0.8 UNI6592
43	PRSL9010PI	Plaque
44	PRVI0176PE	Screw M4x10
45	PRSL8560PI	Earth rotor sector

Reference	Code	Description
46	PRFU6001PE	Auxiliary ring
47	PRSL8575PI	Spacer 10mm
48	Codes on request	Tube
49	PRFU6011PE	Line ring
50	PRTO6436PE	Rod 72.5
51	PRSL8570PI	Spacer 4mm
52	PRSL9175PI	Lower brush holder
53	PRSL9170PI	Upper brush holder
54	Codes on request	Internal protection tube
55	PRVI0126PE	Screw 4x20
56	PRSL9060PI	Cable clamp support
57	PRSL5665PI	1 hole cover

The data and the products illustrated in this brochure may be modified without notice. Under no circumstances can their description have a contractual value.

PRCA0EAE01



TER Tecno Elettrica Ravasi srl

Via Garibaldi 29/31 - 23885 Calco (LC) - Italy

Registered Office - via San Vigilio 2 - 23887 Olgiate Molgora (LC) - Italy

Tel. +39 0399911011 - Fax +39 0399910445 - E-mail: info@terworld.com

www.terworld.com

